RGBW BLUETOOTH HEADLIGHTS

2015-2017 FORD F-150

ISTALLATION IANUAL

















COMPONENTS











TOOLS NEEDED




- **SCREWDRIVERS (+ AND -)**
- **SOCKET WRENCH**
- **SOCKETS**






Remove the 2 plastic pop clips holding the trim in.

STEP




Remove the 2 bolts in the wheel well.

STEP



Release the trim piece.

STEP




Remove the wheel arch trim by away from the vehicle.













Remove the trim by pulling away from the vehicle.

STEP




Remove the two bolts on top of the headlight housing using the screwdriver.

STEP




Remove the bolts holding the plastic reinforcement.

STEP




Remove the final bolt to release the headlight housing.

STEP



Ensure the plastic reinforcement is loose, it is not required to remove the part from the vehicle as a whole unless needed.

STEP




Pull the front of the projector headlight towards you to remove the headlight housing from the vehicle.













Unplug the electrical harness from the back of the headlight housing.

STEP




Install the Aura Control Box by connecting the positive wire for a constant on functionality (always on when battery is on) or an accessory wire (only on when the vehicle is on) which can be found in the Fuse Box. Connect the negative wire to a ground wire.

STEP




Remove headlight housing.

STEP



Connect the round connector from the headlight housings to the control box.


STEP



Install new headlight housing by connecting the electrical harness.

Black and Green Wires: Not needed a connection for DRL Tube to function. Ensure the wires are tied up securely to ensure wires are organized and store away from any metal surface.

STEP




Replace the headlight housing by lining up the tabs and locking it into place.













Replace the bolt to secure the headlight.

STEP 20




Replace the vehicle trim.

STEP




Replace the two bolts on top to secure the headlight housing.

STEP Z




Re-attach the wheel arch trim.

STEP



Replace the bolts to secure the plastic reinforcement.

STEP 22




Replace the 2 bolts securing the trim.








STEP²




Push the trim into place.

STEP 24



Secure the trim by inserting the plastic clip and locking into place.

STEP 25



Test out your headlights using the OPT7 Connect App.







QR CODE TO DOWNLOAD



Download the free "OPT7 CONNECT" App

- App iOS (12+) available on App Store
- Android (6 +) available on Google Play

OPT7 CONNECT APP

- Colors
- Modes
- Door Assist
- Support
- Ability to control up to 4 devices at once

DISCLAIMER

OPT7 Lighting is not liable for damages or personal injuries while installing this product. The Installation Guide is intended as assistance to reduce setup time. OPT7 Lighting assumes no responsibility for improper installation.

If you are unfamiliar with your vehicle or inexperienced with aftermarket upgrades, please seek professional assistance.