

# HONDA CIVIC HATCHBACK TAIL LIGHTS

**WHAT'S INCLUDED** 



## INSTALLATION



#### STEP 1

Open the hatch.



#### STEP 2

Remove the two bolts to free the tail light housing.



#### STEP 3

Push toward the outside of the vehicle to pop the tail light housing out.



### STEP 4

Unplug the four electrical connectors from the factory tail light.



#### STEP 5

Connect the electrical connectors to the new tail light housing.

# INSTALLATION



#### STEP 6

Line up the tabs and pop the new tail light housing in.



#### STEP 7

Secure the tail light housing by re-installing the two bolts that were removed.



#### STEP 8

Remove the plastic trim on the inside of the hatch. Remove the 3 bolts securing the tail light housing.



#### STEP 9

Push from the inside of the hatch to release the tail light housing.



#### STEP 10

Disconnect the electrical connector from the stock tail light housing.



#### STEP 11

Reconnect the electrical connector to the new tail light housing.



#### STEP 12

Secure the tail light housing by inserting and tightening the 3 bolts that were removed. Reattach the plastic trim on the inside of the hatch.



#### STEP 13

Enjoy your new tail lights!

## DISCLAIMER

OPT7 Lighting is not liable for damages or personal injuries while installing this product. The Installation Guide is intended as assistance to reduce setup time. OPT7 Lighting assumes no responsibility for improper installation. If you are unfamiliar with your vehicle or inexperienced with aftermarket upgrades, please seek professional assistance.

